


Home's ventilation

Use of the ventilation

The home's ventilation is controlled by a Smart panel. When the panel is not used, it is in sleep mode. The basic menu is shown when any button is pressed. Select an appropriate operating mode by pressing the centre button: 



Home

Normal air flow. Used when there are people in the home.



Boost

High air flow. Used if the ventilation requirement increases, for example, when cooking, taking a bath or drying laundry or if an unusually large number of people are in the home. The time is set to 60 minutes, after that period the speed returns to Home mode.



Away

Low air flow. Used when no one is present in the home.



Humidity automation


Automatically boost ventilation to remove excess moisture from your home. The symbol for moisture-related boosting is shown on the screen while the automatic system boosts ventilation.



Basic menu

Tip! You can also set the weekly timer to switch between operating modes according to the required diurnal rhythm, or allow the automatic functions to regulate the ventilation automatically. You will find more information about the ventilation unit's functions and settings in the ventilation unit's Instructions for Use.

Alarm

If the ventilation unit detects an alarm or an information message, this is shown on the control panel. The symbol for an active alarm is . **N.B.!** If there is an active alarm in the unit, contact a service company and note the alarm message and the unit's data and manufacturing number.

More information

[Home's ventilation \(video\)](#)

[Use of the Smart panel \(video\)](#)

