

Installation instructions for the TBLZ-54 Louvre Damper COMPACT 02-03


1. General

The louvre damper is designed for installation on the exhaust air and/or outdoor air connection on the top of the COMPACT Air unit. Prevents cold draughts while the air handling unit is switched off.

2. Installation

1. Place the louvre damper on the exhaust air and/or outdoor air connection of the air handling unit.
2. Secure it to the duct system by means of blind rivets.
3. Insulate the damper in accordance with local standards for ventilation ductwork.

Installation Options



Dimensions

