





TPL5



TPL6

Asennusohje TPL5 / TPL6 | Installation instructions TPL5 / TPL6 | Monteringsanvisning TPL5 / TPL6



esim. | e. g | t. ex.

- ST4.2 x 9,5
- M4 x 8
- ST4.8 x 38