

# Modbus RTU/TCP

## COMPACT sizes 02-03,

### program version 1.00 and newer versions

---

#### Overview

ModBus can access single addresses or multiple addresses simultaneously; either reading or writing single bit values or 16-bit values.

A ModBus address contains either a 1-bit discrete value or a 16-bit integer value.

#### Modbus Data formats

Modbus data types are 1-bit values and 16-bit values.

Modbus Type	Description	Reference
Coil Status	Discrete Output	0x
Input Status	Discrete Input	1x
Holding Register	16 bit Output Register	4x
Input Register	16 bit Input Register	3x

#### Supported Modbus commands

The COMPACT air handling unit supports these ModBus commands.

s.  
ds.

Function Code	Description.
01	Read Coil Status
02	Read Input Status
03	Read Holding Registers
04	Read Input Registers
05	Force Single Coil
06	Preset Single Register
08	Diagnostics. Sub-function 00 Only - Return Query Data (loop back).
15	Force multiple coils
16	Preset Multiple Registers

**Coil Status. 1 bit (R/W).**

Modbus	Name	Min/Max	Misc
0x0001	<b>alarm reset</b>	0-1	
	Resets tripped alarms.		
0x0002	<b>Reserve</b>		
0x0003	<b>Reserve</b>		
0x0004	<b>R.HX. Defrost func.</b>	0-1	
	Setting for activating the defrost function for the rotary heat exchanger. 0= Inactive. 1= Active.		
0x0005	<b>Reserve</b>		
0x0006	<b>Reserve</b>		
0x0007	<b>Reserve</b>		
0x0008	<b>Cool operation mode</b>	0-1	
	Setting for cooling between off and auto operation. 0= Inactive. 1= Auto operation.		
0x0009	<b>Int. Night heat func.</b>	0-1	
	Setting for activating the intermittent night heat function. 0= Inactive. 1= Active.		
0x0010	<b>Damper func.</b>	0-1	
	Setting for activating the damper output relay during int. night heat. 0= Inactive. 1= Active.		
0x0011	<b>Summer night cooling</b>	0-1	
	Setting for activating the summer night cool function. 0= Inactive. 1= Active.		
0x0012	<b>Reserve</b>		
0x0013	<b>Outdoor temp compensation</b>	0-1	
	Setting for activating the outdoor temperature compensation function. 0= Inactive. 1= Active.		
0x0014	<b>Outdoor airflow compensation</b>	0-1	
	Setting for activating the outdoor airflow compensation function. 0= Inactive. 1= Active.		
0x0015	<b>Auto. Summer/winter switch</b>	0-1	
	Setting for activating the automatic switch between summer/winter time function. 0= Inactive. 1= Active.		
0x0016	<b>Switch clock func.</b>	0-1	
	Setting for switch clock function type. 0=Stop - low speed - high speed. 1=Low speed - high speed.		
0x0017	<b>Internal fire alarm func.</b>	0-1	
	Setting for activating the internal fire alarm function. 0= Inactive. 1= Active.		
0x0018	<b>Reserve</b>		

<b>0x0019</b>	<b>External alarm 1 active at closure</b>	0-1	
	Setting for external alarm number 1 condition to be activated. 0=Alarm at closed input. 1=Alarm at open input.		
<b>0x0020</b>	<b>External alarm 2 active at closure</b>	0-1	
	Setting for external alarm number 2 condition to be activated. 0=Alarm at closed input. 1=Alarm at open input.		
<b>0x0021</b>	<b>Reserve</b>		
<b>0x0022</b>	<b>Reserve</b>		
<b>0x0023</b>	<b>Reserve</b>		
<b>0x0024</b>	<b>External fire alarm func.</b>	0-1	
	Setting for external fire resetting function. 0=Manual. 1=Automatic.		
<b>0x0025</b>	<b>External alarm 1 func.</b>	0-1	
	Setting for external alarm 1 resetting function. 0=Manual. 1=Automatic.		
<b>0x0026</b>	<b>External alarm 2 func.</b>	0-1	
	Setting for external alarm 2 resetting function. 0=Manual. 1=Automatic.		
<b>0x0027</b>	<b>Reserve</b>	0-1	
<b>0x0028</b>	<b>Reserve</b>	0-1	
<b>0x0029</b>	<b>Morningboost damper func.</b>	0-1	
	Setting for activating the morningboost damper function. 0= Inactive. 1= Active.		
<b>0x0030</b>	<b>Morningboost extract func.</b>	0-1	
	Setting for activating the morningboost extract air fan function. 0= Inactive. 1= Active.		
<b>0x0031</b>	<b>Filter func.</b>	0-1	
	Setting for filter between calculated and pressure sensors. 0=Calculated. 1=Pressure sensors.		
<b>0x0032</b>	<b>Iqnomiq Plus module no.6 Cooling</b>	0-1	
	Setting for activating Iqnomiq Plus no.6 Cooling module. 0=Inactive. 1=Active.		
<b>0x0033</b>	<b>Airing auto func.</b>	0-1	
	Setting for activating the airing auto function. 0=Inactive. 1=Active.		

**Input Status. 1 bit (RO).**

Modbus	Name	Min/Max	Misc
1x0001	<b>Heat output</b>	0-1	
	Status for relay output.		
1x0002	<b>Cool output 1</b>	0-1	
	Status for relay output.		
1x0003	<b>Cool output 2</b>	0-1	
	Status for relay output.		
1x0004	<b>Low speed output</b>	0-1	
	Status for relay output.		
1x0005	<b>High speed output</b>	0-1	
	Status for relay output.		
1x0006	<b>A-alarm.</b>	0-1	
	Status for relay output.		
1x0007	<b>B-alarm.</b>	0-1	
	Status for relay output.		
1x0008	<b>Operation output</b>	0-1	
	Status for relay output.		
1x0009	<b>Damper output</b>	0-1	
	Status for relay output.		
1x0010	<b>External low speed input</b>	0-1	
	Status for digital input.		
1x0011	<b>External high speed input</b>	0-1	
	Status for digital input.		
1x0012	<b>External alarm 1 input</b>	0-1	
	Status for digital input.		
1x0013	<b>External alarm 2 input</b>	0-1	
	Status for digital input.		
1x0014	<b>External fire alarm input.</b>	0-1	
	Status for digital input.		
1x0015	<b>External stop input</b>	0-1	
	Status for digital input.		
1x0016	<b>DIP Switch 1</b>	0-1	
	Status for dip switch setting.		
1x0017	<b>DIP Switch 2</b>	0-1	
	Status for dip switch setting.		
1x0018	<b>DIP Switch 3</b>	0-1	
	Status for dip switch setting.		
1x0019	<b>DIP Switch 4</b>	0-1	
	Status for dip switch setting.		
1x0020	<b>DIP Switch 5</b>	0-1	
	Status for dip switch setting.		
1x0021	<b>DIP Switch 6</b>	0-1	
	Status for dip switch setting.		
1x0022	<b>Reserve</b>		
1x0023	<b>Reserve</b>		

1x0024	Reserve		
1x0025	R.HX rotation monitor	0-1	
	Status from the rotation detector.		
1x0026	Reserve		
1x0027	Reserve		
1x0028	Reserve		
1x0029	Pre-heat output	0-1	
	Status for relay output.		
1x0030	Recirculation output	0-1	
	Status for relay output.		
1x0031	Booster output	0-1	
	Status for relay output.		
1x0032	Reserve		
1x0033	Reserve		
1x0034	Reserve		
1x0035	Reserve		
1x0036	Reserve		
1x0037	Reserve		
1x0038	Reserve		
1x0039	Reserve		
1x0040	Reserve		
1x0041	Reserve		
1x0042	Reserve		
1x0043	Reserve		
1x0044	Reserve		
1x0045	Reserve		
1x0046	Reserve		

1x0047	Reserve		
1x0048	Reserve		
1x0049	Alarm number 1	0-1	
	Status if alarm number 1 is active.		
1x0050	Alarm number 2	0-1	
	Status if alarm number 2 is active.		
1x0051	Alarm number 3	0-1	
	Status if alarm number 3 is active.		
1x0052 ...1x0247	...		
	...		
1x0248	Alarm number 200	0-1	
	Status if alarm number 200 is active.		
1x0249	Info number 1	0-1	
	Status if info number 1 is active.		
1x0250	Info number 2	0-1	
	Status if info number 2 is active.		
1x0251	Info number 3	0-1	
	Status if info number 3 is active.		
1x0252 ...1x0347	...		
	...		
1x0348	Info number 100	0-1	
	Status if info number 100 is active.		

**Input Registers. 16-bit integer value (RO).**

Modbus	Name	Min/Max	Misc
3x0001	<b>SA Airflow</b>	0-360l/s	
	Present supply airflow.		
3x0002	<b>SA Airflow regulator</b>	0-360l/s	
	Present supply airflow regulator setpoint.		
3x0003	<b>EA Airflow</b>	0-360l/s	
	Present extract airflow.		
3x0004	<b>EA Airflow regulator</b>	0-360l/s	
	Present extract airflow regulator setpoint.		
3x0005	<b>SA Duct pressure</b>	0-750Pa	
	Present supply air duct pressure.		
3x0006	<b>SA Duct pressure regulator</b>	0-750Pa	
	Present supply air duct pressure regulator setpoint.		
3x0007	<b>EA Duct pressure</b>	0-750Pa	
	Present extract air duct pressure.		
3x0008	<b>EA Duct pressure regulator</b>	0-750Pa	
	Present extract air duct pressure regulator setpoint.		
3x0009	<b>Reserve</b>		
3x0010	<b>SA VAV demand regulator</b>	0-100.00%	
	Present supply air VAV demand regulator setpoint.		
3x0011	<b>Reserve</b>		
3x0012	<b>EA VAV demand regulator</b>	0-100.00%	
	Present supply air VAV demand regulator setpoint.		
3x0013	<b>SA Fan level</b>	0-100.00%	
	Present running level for the supply air fan.		
3x0014	<b>EA Fan level</b>	0-100.00%	
	Present running level for the extract air fan.		
3x0015	<b>SA Fan effect</b>	0-500W	
	Present power consumption level for the supply air fan.		
3x0016	<b>EA Fan effect</b>	0-500W	
	Present power consumption level for the extract air fan.		
3x0017	<b>SFP</b>	0.0-9.9	
	SFP supply air + extract air.		
3x0018	<b>Reserve</b>		
3x0019	<b>Reserve</b>		
3x0020	<b>SA Voltage</b>	0-500V	
	Present voltage level for the supply air fan.		
3x0021	<b>EA Voltage</b>	0-500V	
	Present voltage level for the extract air fan.		
3x0022	<b>SA Current</b>	0-2.000A	
	Present current level for the supply air fan.		
3x0023	<b>EA Current</b>	0-2.000A	

	Present current level for the extract air fan.		
<b>3x0024</b>	<b>SA Airflow pressure</b>	0-3000Pa	
	Present airflow pressure in the supply air fan inlet.		
<b>3x0025</b>	<b>EA Airflow pressure</b>	0-3000Pa	
	Present airflow pressure in the extract air fan inlet.		
<b>3x0026</b>	<b>SA Temp regulator</b>	5.00-60.00°C	
	Present supply air temperature regulator setpoint.		
<b>3x0027</b>	<b>EA Temp regulator</b>	5.00-40.00°C	
	Present extract air temperature regulator setpoint.		
<b>3x0028</b>	<b>SA Temperature</b>	5.00-40.00°C	
	Present supply air temperature.		
<b>3x0029</b>	<b>EA/Room temperature</b>	5.00-40.00°C	
	Present extract air/room temperature in the unit.		
<b>3x0030</b>	<b>Outdoor temperatur</b>	5.00-40.00°C	
	Present outdoor air temperature in the unit.		
<b>3x0031</b>	<b>EA/Room temperature (external)</b>	5.00-40.00°C	
	Present room temperature external from the unit.		
<b>3x0032</b>	<b>Outdoor temperatur (external)</b>	5.00-40.00°C	
	Present outdoor air temperature external from the unit.		
<b>3x0033</b>	<b>Anti frost temperature</b>	5-40.00°C	
	Present anti frost temperature for water reheating coils.		
<b>3x0034</b>	<b>Reserve</b>		
<b>3x0035</b>	<b>Reserve</b>		
<b>3x0036</b>	<b>R. Heat exchange level</b>	0-100.00%	
	Present operation level from rotary heat exchange.		
<b>3x0037</b>	<b>Reheat level</b>	0-100.00%	
	Present level of reheat.		
<b>3x0038</b>	<b>SA Down regulation level</b>	0-100.00%	
	Present level of supply airflow down regulation.		
<b>3x0039</b>	<b>Reserve</b>		
<b>3x0040</b>	<b>Cooling level</b>	0-100.00%	
	Present level of cooling.		
<b>3x0041</b>	<b>Heating boost level</b>	0-100.00%	
	Present level of heating boost.		
<b>3x0042</b>	<b>Cooling boost level</b>	0-100.00%	
	Present level of cooling boost.		
<b>3x0043</b>	<b>HX pressure level</b>	0-1000Pa	
	Present pressure drop for the rotary heat exchanger.		
<b>3x0044</b>	<b>HX pressure alarm limit</b>	0-1000Pa	
	Present pressure drop alarm limit for the rotary heat exchanger.		
<b>3x0045</b>	<b>HX temperature</b>	0-100.00°C	
	Present temperature inside the control unit for the rotary heat exchanger.		
<b>3x0046</b>	<b>Effect reduction level</b>	0-100.00%	



	Present level of max output signal for electrical reheaters, active during low supply airflow.		
<b>3x0047</b>	<b>Anti frost temp setpoint/operation</b>	10.00-16.00°C	
	Present anti frost temperature setpoint for water reheating coils during unit operation.		
<b>3x0048</b>	<b>Anti frost temp setpoint/stop</b>	15.00-40.00°C	
	Present anti frost temperature setpoint for water reheating coils when the unit is in stop.		
<b>3x0049</b>	<b>Anti frost temp alarm limit</b>	5.00-30.00°C	
	Setting of antifrost temperature alarm limit.		
<b>3x0050</b>	<b>Supply air filter pressure level</b>	0-3000Pa	
	Present supply air filter pressure drop.		
<b>3x0051</b>	<b>Supply air filter pressure alarm limit.</b>	0-1000Pa	
	Present supply air filter pressure alarm limit.		
<b>3x0052</b>	<b>Supply air filter pressure level, new</b>	0-1000Pa	
	Supply air filter pressure saved from calibration.		
<b>3x0053</b>	<b>Extract air filter pressure level</b>	0-3000Pa	
	Present extract air filter pressure drop.		
<b>3x0054</b>	<b>Extract air filter pressure alarm limit.</b>	0-1000Pa	
	Present extract air filter pressure alarm limit.		
<b>3x0055</b>	<b>Extract air filter pressure level, new</b>	0-1000Pa	
	Extract air filter pressure saved from calibration.		
<b>3x0056</b>	<b>Reserve</b>		
<b>3x0057</b>	<b>Coil type</b>	0-20	
	Present connected reheat coil type.		
<b>3x0058</b>	<b>Cool step time</b>	0-600s	
	Present time between cool step shift.		
<b>3x0059</b>	<b>Cool relay 1 restart time</b>	0-1800s	
	Present time between two starts of cool relay 1.		
<b>3x0060</b>	<b>Cool relay 2 restart time</b>	0-1800s	
	Present time between two starts of cool relay 2.		
<b>3x0061</b>	<b>Programversion, HMI</b>	0-10.00	
	Present programversion for the handterminal.		
<b>3x0062</b>	<b>Programversion, HMI-slave</b>	0-10.00	
	Present programversion for the extra handterminal.		
<b>3x0063</b>	<b>Programversion, main controller.</b>	0-10.00	
	Present programversion for the main control unit.		
<b>3x0064</b>	<b>Programversion, SA FC-1.</b>	0-10.00	
	Present programversion for the supply air frequency converter no.1.		
<b>3x0065</b>	<b>Programversion, SA FC-2.</b>	0-10.00	
	Present programversion for the supply air frequency converter no.2.		
<b>3x0066</b>	<b>Programversion, EA FC-1.</b>	0-10.00	
	Present programversion for the extract air frequency converter no.1.		
<b>3x0067</b>	<b>Programversion, EA FC-2.</b>	0-10.00	
	Present programversion for the extract air frequency converter no.2.		
<b>3x0068</b>	<b>Programversion, HX control unit</b>	0-10.00	

	Present programversion for the rotary heat exchange control unit.		
<b>3x0069</b>	<b>Weekday</b>	0 - 6	
	Present weekday for the unit's internal clock.		
<b>3x0070</b>	<b>Extended low speed op. Hours</b>	0-23	
	Present time for extended low speed operation.		
<b>3x0071</b>	<b>Extended low speed op. Minutes</b>	0-59	
	Present time for extended low speed operation.		
<b>3x0072</b>	<b>Extended high speed op. Hours</b>	0-23	
	Present time for extended high speed operation.		
<b>3x0073</b>	<b>Extended high speed op. Minutes</b>	0-59	
	Present time for extended high speed operation.		
<b>3x0074</b>	<b>SA Fan operation time</b>	0-9999	
	Present operation time for the supply air fan, measured in minutes and present in days (24h).		
<b>3x0075</b>	<b>EA Fan operation time</b>	0-9999	
	Present operation time for the extract air fan, measured in minutes and present in days (24h).		
<b>3x0076</b>	<b>Cool operation time</b>	0-9999	
	Present operation time for cooling, measured in minutes and present in days (24h).		
<b>3x0077</b>	<b>Heat exchange operation time</b>	0-9999	
	Present operation time for heat exchange, measured in minutes and present in days (24h).		
<b>3x0078</b>	<b>Reheat operation time</b>	0-9999	
	Present operation time for reheat, measured in minutes and present in days (24h).		
<b>3x0079</b>	<b>Present tripped alarm</b>	0-200	
	Present tripped alarm number with highest priority.		
<b>3x0080</b>	<b>Active not tripped alarm no.1</b>	0-200	
	Present active alarm in delay.		
<b>3x0081</b>	<b>Active not tripped alarm no.2</b>	0-200	
	Present active alarm in delay.		
<b>3x0082</b>	<b>Active not tripped alarm no.3</b>	0-200	
	Present active alarm in delay.		
<b>3x0083</b>	<b>SA Fan size</b>	02 - 03	
	Present supply air fan size.		
<b>3x0084</b>	<b>EA Fan size</b>	02 - 03	
	Present extract air fan size.		
<b>3x0085</b>	<b>Operation mode 1</b>	0 - 18,255	

	0=Manual stop. 1=Ext. stop. 2=Com. stop 1. 3=Manual high speed. 4=Summer night cooling. 5=Int. night heat. 6=Manual low speed. 7=Ext. high speed. 8=Com. high speed. 9=Year channel stop. 10=Year channel high speed. 11=Year channel low speed. 12=Time channel high speed. 13=Ext. low speed. 14=Com. low speed. 15=Time channel low speed. 16=Time channel stop. 17=Low speed=stop. 18=Com. stop 2. 255=		
<b>3x0086</b>	<b>Operation mode 2</b>	0 - 24	
	0= 1=Coold air recovery. 2=Cooling boost. 3=SA down regulation. 4=HX defrosting. 5=Anti frost func. active. 6=Effect reduction. 7=Startup. 8=Zero calibration. 9=Extended low speed. 10=Extended high speed. 11=Air adjustment. 12=Cooling off. 13=Purging R.HX. 14=Extended R.HX. op. 15=Filter calibration. 16=R.HX. calibration 17=Morning boost. 18=Heating boost. 19=Alarm. 20=Cooling pressure reduction. 21=Startup extract air fan. 22=Reserve. 23=Airing. 24=Heating.		
<b>3x0087</b>	<b>Operation mode, manual</b>	0 - 3	
	Present manual operation set on the unit's handterminal. 0=Stop. 1=Auto operation. 2=Manual low speed. 3=Manual high speed.		
<b>3x0088</b>	<b>Copy of Input Status 1-16.</b>	0-65535	
	Bit 0=1x0001 Bit 1=1x0002 Bit 15=1x0016		
<b>3x0089</b>	<b>Copy of Input Status 17-32.</b>	0-65535	

	Bit 0=1x00017 Bit 1=1x00018 Bit 15=1x0032		
3x0090	<b>Copy of Input Status 33-48.</b>	0-65535	
	Bit 0=1x00033 Bit 1=1x00034 Bit 15=1x0048		
3x0091	<b>Heat exchange regulator</b>	0-100.00%	
	Present level of heat exchange regulator.		
3x0092	<b>Reserve</b>		
3x0093	<b>Reserve</b>		
3x0094	<b>Reserve</b>		
3x0095	<b>Reserve</b>		
3x0096	<b>Reserve</b>		
3x0097	<b>Reserve</b>		
3x0098	<b>Reserve</b>		
3x0099	<b>Reserve</b>		
3x0100	<b>Reserve</b>		
3x0101	<b>Reserve</b>		
3x0102	<b>Reserve</b>		
3x0103	<b>Reserve</b>		
3x0104	<b>Reserve</b>		
3x0105	<b>Reserve</b>		
3x0106	<b>R.HX. Efficiency</b>	0-100.00%	
	Calculated level of rotary heat exchanger efficiency.		
3x0107	<b>Reserve</b>		
3x0108	<b>Reserve</b>		
3x0109	<b>Supply air prefilter pressure level</b>	0-3000Pa	
	Present supply air prefilter pressure drop.		
3x0110	<b>Supply air prefilter pressure alarm limit.</b>	0-1000Pa	
	Present supply air prefilter pressure alarm limit.		
3x0111	<b>Supply air prefilter pressure level, new</b>	0-1000Pa	
	Supply air prefilter pressure saved from calibration.		

3x0112	<b>Extract air prefilter pressure level</b>	0-3000Pa	
	Present extract air prefilter pressure drop.		
3x0113	<b>Extract air prefilter pressure alarm limit.</b>	0-1000Pa	
	Present extract air prefilter pressure alarm limit.		
3x0114	<b>Extract air prefilter pressure level, new</b>	0-1000Pa	
	Extract air prefilter pressure saved from calibration.		
3x0115	<b>Reserve</b>		
3x0116	<b>Reserve</b>		
3x0117	<b>Reserve</b>		
3x0118	<b>Reserve</b>		
3x0119	<b>Reserve</b>		
3x0120	<b>Reserve</b>		
3x0121	<b>Reserve</b>		
3x0122	<b>Reserve</b>		
3x0123	<b>Reserve</b>		
3x0124	<b>Reserve</b>		
3x0125	<b>Pre-heating air temperature</b>	0.00-40.00°C	
	Present pre-heating air temperature.		
3x0126	<b>Pre-heating level</b>	0-100.00%	
	Present level of pre-heating.		
3x0127	<b>Pre-heating anti frost temperature</b>	0-40.00°C	
	Present anti frost temperature for water pre-heating coils.		
3x0128	<b>Reserve</b>		
3x0129	<b>Reserve</b>		
3x0130	<b>Reserve</b>		
3x0131	<b>Reserve</b>		
3x0132	<b>Reserve</b>		
3x0133	<b>Reserve</b>		
3x0134	<b>Preheat operation time</b>	0-30000	
	Present operation time for preheat, measured in minutes and present in days (24h).		

<b>3x0135</b>	<b>Reserve</b>		
<b>3x0136</b>	<b>Reserve</b>		
<b>3x0137</b>	<b>Demand VOC Level</b>	0-100.00%	
	Present level of demand VOC input.		
<b>3x0138</b>	<b>Demand Vin Level</b>	0-100.00%	
	Present level of demand 0-10VDC input.		
<b>3x0139</b>	<b>SA Filter level calculated</b>	0-100.00%	
	Present level of calculated supply air filter.		
<b>3x0140</b>	<b>EA Filter level calculated</b>	0-100.00%	
	Present level of calculated extract air filter.		

**Holding Registers. 16-bit integer value (R/W).**

Modbus	Name	Min/Max	Misc
4x0001	<b>SA Low speed airflow setpoint</b>	0-360l/s	
	Supply airflow setpoint for the unit when running in low speed operation.		
4x0002	<b>SA High speed airflow setpoint</b>	0-360l/s	
	Supply airflow setpoint for the unit when running in high speed operation.		
4x0003	<b>SA Max speed airflow setpoint</b>	0-360l/s	
	Supply airflow max. limit for the unit when the low/high speed operation setpoint is altered by boosting function etc.		
4x0004	<b>SA Min speed airflow setpoint</b>	0-360l/s	
	Supply airflow min. limit for the unit when the low/high speed operation setpoint is altered when running in fan regulation mode VAV demand.		
4x0005	<b>EA Low speed airflow setpoint</b>	0-360l/s	
	Extract airflow setpoint for the unit when running in low speed operation.		
4x0006	<b>EA High speed airflow setpoint</b>	0-360l/s	
	Extract airflow setpoint for the unit when running in high speed operation.		
4x0007	<b>EA Max speed airflow setpoint</b>	0-360l/s	
	Extract airflow max. limit for the unit when the low/high speed operation setpoint is altered by boosting function etc.		
4x0008	<b>EA Min speed airflow setpoint</b>	0-360l/s	
	Extract airflow min. limit for the unit when the low/high speed operation setpoint is altered when running in fan regulation mode VAV demand.		
4x0009	<b>SA Low speed pressure setpoint</b>	0-750Pa	
	Supply air duct pressure setpoint for the unit when running in low speed operation.		
4x0010	<b>SA High speed pressure setpoint</b>	0-750Pa	
	Supply air duct pressure for the unit when running in high speed operation.		
4x0011	<b>SA Max speed output signal</b>	10.00-100.00%	
	Max. limit for the supply air fan speed when running in pressure regulation mode.		
4x0012	<b>SA Max speed pressure setpoint</b>	0-750Pa	
	Supply air duct pressure max. limit for the unit when the low/high speed operation setpoint is altered by boosting function etc.		
4x0013	<b>EA Low speed pressure setpoint</b>	0-750Pa	
	Extract air duct pressure setpoint for the unit when running in low speed operation.		
4x0014	<b>EA High speed pressure setpoint</b>	0-750Pa	
	Extract air duct pressure setpoint for the unit when running in high speed operation.		
4x0015	<b>EA Max speed output signal</b>	10.00-100.00%	
	Max. limit for the extract air fan speed when running in pressure regulation mode.		

<b>4x0016</b>	<b>EA Max speed pressure setpoint</b>	0-750Pa	
	Extract air duct pressure max. limit for the unit when the low/high speed operation setpoint is altered by boosting function etc.		
<b>4x0017</b>	<b>SA Low speed demand setpoint</b>	0-100.00%	
	Supply air setpoint for the 0-10V input signal on terminal 35..37 for the unit when running in low speed operation.		
<b>4x0018</b>	<b>SA High speed demand setpoint</b>	0-100.00%	
	Supply air setpoint for the 0-10V input signal on terminal 35..37 for the unit when running in high speed operation.		
<b>4x0019</b>	<b>EA Low speed demand setpoint</b>	0-100.00%	
	Extract air setpoint for the 0-10V input signal on terminal 35..37 for the unit when running in low speed operation.		
<b>4x0020</b>	<b>EA High speed demand setpoint</b>	0-100.00%	
	Extract air setpoint for the 0-10V input signal on terminal 35..37 for the unit when running in high speed operation.		
<b>4x0021</b>	<b>SA Airflow regulation zone</b>	1.00 - 10.00	
	Supply airflow regulation zone setting in % of the present airflow setpoint that the regulator is allowed to work within.		
<b>4x0022</b>	<b>SA Airflow C-factor</b>	0.005 - 2.500	
	Supply airflow regulator affection setting.		
<b>4x0023</b>	<b>EA Airflow regulation zone</b>	1.00 - 10.00	
	Extract airflow regulation zone setting in % of the present airflow setpoint that the regulator is allowed to work within.		
<b>4x0024</b>	<b>EA Airflow C-factor</b>	0.005 - 2.500	
	Extract airflow regulator affection setting.		
<b>4x0025</b>	<b>SA Pressure regulation zone</b>	1.00 - 10.00	
	Supply air pressure regulation zone setting in % of the present duct pressure setpoint that the regulator is allowed to work within.		
<b>4x0026</b>	<b>SA Pressure C-factor</b>	0.005 - 2.500	
	Supply air pressure regulator affection setting.		
<b>4x0027</b>	<b>EA Pressure regulation zone</b>	1.00 - 10.00	
	Extract air pressure regulation zone setting in % of the present duct pressure setpoint that the regulator is allowed to work within.		
<b>4x0028</b>	<b>EA Pressure C-factor</b>	0.005 - 2.500	
	Extract air pressure regulator affection setting.		
<b>4x0029</b>	<b>SA Demand P-band.</b>	1.00 - 100.00	
	Supply air demand regulator P-band setting.		
<b>4x0030</b>	<b>SA Demand C-factor</b>	0.005 - 2.500	
	Supply air demand regulator affection setting.		
<b>4x0031</b>	<b>EA Demand P-band.</b>	1.00 - 100.00	
	Extract air demand regulator P-band setting.		
<b>4x0032</b>	<b>EA Demand C-factor</b>	0.005 - 2.500	
	Extract air demand regulator affection setting.		
<b>4x0033</b>	<b>ERS 1 Diff</b>	1.00 - 7.00°C	
	Supply air temperature difference setting according to the diagram for ERS 1.		
<b>4x0034</b>	<b>ERS 1 Breakpoint</b>	12.00 - 26.00°C	
	Breakpoint setting according to the diagram for ERS 1.		



<b>4x0035</b>	<b>ERS 2 Breakpoint X1</b>	10.00-38.00°C	
	Breakpoint X1 setting according to the diagram for ERS 2.		
<b>4x0036</b>	<b>ERS 2 Breakpoint Y1</b>	10.00-40.00°C	
	Breakpoint Y1 setting according to the diagram for ERS 2.		
<b>4x0037</b>	<b>ERS 2 Breakpoint X2</b>	11.00-39.00°C	
	Breakpoint X2 setting according to the diagram for ERS 2.		
<b>4x0038</b>	<b>ERS 2 Breakpoint Y2</b>	10.00-40.00°C	
	Breakpoint Y2 setting according to the diagram for ERS 2.		
<b>4x0039</b>	<b>ERS 2 Breakpoint X3</b>	12.00-40.00°C	
	Breakpoint X3 setting according to the diagram for ERS 2.		
<b>4x0040</b>	<b>ERS 2 Breakpoint Y3</b>	10.00-40.00°C	
	Breakpoint Y3 setting according to the diagram for ERS 2.		
<b>4x0041</b>	<b>SA Temperature setpoint</b>	10.00-40.00°C	
	Supply air temperature setting, for supply air temp regulation mode.		
<b>4x0042</b>	<b>EA/Room Temperature setpoint</b>	10.00-30.00°C	
	Extract air/room temperature setting, for Extract air/room temp regulation mode.		
<b>4x0043</b>	<b>SA Min temp setpoint</b>	8.00-20.00°C	
	Supply air min.setpoint during EA/room regulation mode.		
<b>4x0044</b>	<b>SA Max temp setpoint</b>	16.00-50.00°C	
	Supply air max.setpoint during EA/room regulation mode.		
<b>4x0045</b>	<b>SA Temperature P-band</b>	1.00 - 40.00	
	Supply air temperature regulator P-band setting.		
<b>4x0046</b>	<b>EA/Room Temperature P-band</b>	1.00 - 40.00	
	Extract air/room temperature regulator P-band setting.		
<b>4x0047</b>	<b>SA HX. Reg C-factor</b>	0.000 - 2.500	
	Supply air heat exchange regulator affection setting.		
<b>4x0048</b>	<b>EA/Room HX. Reg C-factor</b>	0.000 - 2.500	
	Extract air/room heat exchange regulator affection setting.		
<b>4x0049</b>	<b>SA Heat Reg C-factor</b>	0.000 - 2.500	
	Supply air reheat regulator affection setting.		
<b>4x0050</b>	<b>EA/Room Heat Reg C-factor</b>	0.000 - 2.500	
	Extract air/room reheat regulator affection setting.		
<b>4x0051</b>	<b>Reserve</b>		
<b>4x0052</b>	<b>Reserve</b>		
<b>4x0053</b>	<b>Reserve</b>		
<b>4x0054</b>	<b>Reserve</b>		

<b>4x0055</b>	<b>SA Down regulation Reg C-factor</b>	0.000 - 2.500	
	Supply air reheat regulator affection setting.		
<b>4x0056</b>	<b>Reserve</b>		
<b>4x0057</b>	<b>SA Cool reg C-factor</b>	0.000 - 2.500	
	Supply air cool regulator affection setting.		
<b>4x0058</b>	<b>EA/Room Cool reg C-factor</b>	0.000 - 2.500	
	Extract air/room cool regulator affection setting.		
<b>4x0059</b>	<b>SA Cooling boost C-factor</b>	0.000 - 2.500	
	Supply air cooling boost affection setting.		
<b>4x0060</b>	<b>EA/Room Cooling boost reg C-factor</b>	0.000 - 2.500	
	Extract air/room cooling boost regulator affection setting.		
<b>4x0061</b>	<b>HX Pressure alarm set.</b>	30 - 100Pa	
	Heat exchange pressure alarm limit setting (alarm no.38).		
<b>4x0062</b>	<b>Reserve</b>		
<b>4x0063</b>	<b>Reserve</b>		
<b>4x0064</b>	<b>Cooling off set.</b>	10 - 50%	
	Cooling off airflow setting in % of max. airflow.		
<b>4x0065</b>	<b>SA Down regulation neutral zone</b>	0.00-10.00°C	
	Neutral zone setting before downregulation is permitted.		
<b>4x0066</b>	<b>Cool Outdoor temp limit.1</b>	0.00-25.00°C	
	Outdoor temperature limit setting for cooling stage 1.		
<b>4x0067</b>	<b>Cool Outdoor temp limit.2</b>	0.00-25.00°C	
	Outdoor temperature limit setting for cooling stage 2.		
<b>4x0068</b>	<b>Cool Outdoor temp limit.3</b>	0.00-25.00°C	
	Outdoor temperature limit setting for cooling stage 3.		
<b>4x0069</b>	<b>Temperature reg. Neutral zone</b>	0.50-10.00°C	
	Neutral zone setting before shift between heating and cooling.		
<b>4x0070</b>	<b>SA Cool min air flow</b>	0-360l/s	
	Supply air min. air flow setting for cooling.		
<b>4x0071</b>	<b>EA Cool min air flow</b>	0-360l/s	
	Extract air min. air flow setting for cooling.		
<b>4x0072</b>	<b>Heating boost start limit</b>	2.00-10.00°C	
	Heating boost start temperature limit.		
<b>4x0073</b>	<b>Cooling boost start limit</b>	2.00-10.00°C	
	Cooling boost (comfort) start temperature limit.		
<b>4x0074</b>	<b>SA Filter alarm limit</b>	0-1000Pa	
	Supply air filter pressure alarm limit setting.		
<b>4x0075</b>	<b>EA Filter alarm limit</b>	0-1000Pa	

	Extract air filter pressure alarm limit setting.		
<b>4x0076</b>	<b>Int. Night heat room start temp</b>	5.00-40.00°C	
	Intermittent night heat function, extract air temperature setting for start.		
<b>4x0077</b>	<b>Int. Night heat room stop temp</b>	5.00-40.00°C	
	Intermittent night heat function, extract air temperature setting for stop.		
<b>4x0078</b>	<b>Int. Night heat SA temp setpoint</b>	5.00-40.00°C	
	Intermittent night heat function, supply air temperature setpoint during night heat.		
<b>4x0079</b>	<b>Int. Night heat SA airflow setpoint</b>	0-360l/s	
	Intermittent night heat function, supply airflow setpoint during night heat.		
<b>4x0080</b>	<b>Int. Night heat EA airflow setpoint</b>	0-360l/s	
	Intermittent night heat function, extract airflow setpoint during night heat.		
<b>4x0081</b>	<b>Summer night cool EA start temp</b>	17.00-27.00°C	
	Summer night cool function, extract air temperature setting for start.		
<b>4x0082</b>	<b>Summer night cool EA stop temp</b>	12.00-22.00°C	
	Summer night cool function, extract air temperature setting for stop.		
<b>4x0083</b>	<b>Summer night cool outdoor temp limit</b>	5.00-15.00°C	
	Summer night cool function, outdoor temperature limit.		
<b>4x0084</b>	<b>Summer night cool SA temp setpoint</b>	10.00-20.00°C	
	Summer night cool function, supply air temperature setpoint during summer night cool.		
<b>4x0085</b>	<b>Outdoor temp comp. Winter X1.</b>	-30.00-(-10.00)°C	
	Endpoint of winter compensation.		
<b>4x0086</b>	<b>Outdoor temp comp. Winter X2.</b>	-10.00-15.00°C	
	Startpoint of winter compensation.		
<b>4x0087</b>	<b>Outdoor temp comp. Winter Y1.</b>	0.00-10.00°C	
	Level of winter compensation at X1.		
<b>4x0088</b>	<b>Outdoor temp comp. Summer X3.</b>	15.00-25.00°C	
	Startpoint of summer compensation.		
<b>4x0089</b>	<b>Outdoor temp comp. Summer X4.</b>	25.00-40.00°C	
	Endpoint of summer compensation.		
<b>4x0090</b>	<b>Outdoor temp comp. Summer Y2.</b>	-10.00-10.00°C	
	Level of summer compensation at X4.		
<b>4x0091</b>	<b>Outdoor airflow comp. Winter X1.</b>	-30.00-(-10.00)°C	
	Endpoint of winter compensation.		
<b>4x0092</b>	<b>Outdoor airflow comp. Winter X2.</b>	-10.00-15.00°C	
	Startpoint of winter compensation.		
<b>4x0093</b>	<b>Outdoor airflow comp. Winter Y1.</b>	0-50.00%	
	Level of airflow compensation at X1.		
<b>4x0094</b>	<b>Reserve</b>		
<b>4x0095</b>	<b>EA/Room min temp alarm limit</b>	8.00-20.00°C	
	Setting for min extract air /room temp alarm no.40.		

<b>4x0096</b>	<b>SA Deviation alarm limit</b>	2.00-15.00°C	
	Setting for supply air temperature below present setpoint, alarm no.41.		
<b>4x0097</b>	<b>Reserve</b>		
<b>4x0098</b>	<b>SA Fan regulation mode</b>	0 - 3	
	Setting of regulation type for the supply air fan. 0=Airflow reg. 1=Pressure reg. 2=Demand reg. 3=Slave controlled by EA fan.		
<b>4x0099</b>	<b>EA Fan regulation mode</b>	0 - 3	
	Setting of regulation type for the extract air fan. 0=Airflow reg. 1=Pressure reg. 2=Demand reg. 3=Slave controlled by SA fan.		
<b>4x0100</b>	<b>ERS Step</b>	1 - 4	
	Setting of curve when temperature is above breakpoint.		
<b>4x0101</b>	<b>Temperature regulation mode.</b>	0 - 3	
	Setting of temperature regulation type. 0=ERS 1 reg. 1=ERS 2 reg. 2=SA reg. 3=EA/Room reg.		
<b>4x0102</b>	<b>Cooling off periode</b>	60 - 1500s	
	Time setting for cooling off electrical heating coil.		
<b>4x0103</b>	<b>Cool step time</b>	0 - 600s	
	Time setting between cool step shift.		
<b>4x0104</b>	<b>Cool restart time</b>	60 - 900s	
	Setting of time between two starts of the cool relays.		
<b>4x0105</b>	<b>Cool regulation mode</b>	0 - 4	
	Setting of cool regulation type 0=Controlled 0-10V 1=Controlled 10-0V 2=On/Off 1-step 3=On/Off 2-steps 4=On/Off 3-steps binary		
<b>4x0106</b>	<b>Heating boost regulation mode.</b>	0 - 1	
	Setting for heating boost function. 0=Inactive. 1=Active.		
<b>4x0107</b>	<b>Cooling boost regulation mode.</b>	0 - 5	
	Setting of cooling boost regulation type. 0=Inactive. 1=Comfort. 2=Economy. 3=Sequence. 4=Comfort+economy 5=Economy+sequence		
<b>4x0108</b>	<b>Filter calibration mode</b>	0 - 4	

	Setting for required filtercalibration. 0=Inactive. 1=SA+EA-Filter. 2=SA-Filter. 3=EA-Filter. 4=HX.		
<b>4x0109</b>	<b>Air adjustment time, minutes</b>	0 - 1728	
	Setting for amount of minutes to air adjustment function.		
<b>4x0110</b>	<b>Air adjustment time, hours</b>	0 - 72	
	Setting for amount of hours to air adjustment function.		
<b>4x0111</b>	<b>Handterminal language</b>	0 - 18	
	0=Svenska 1=Norsk 2=Dansk 3=Suomi 4=English 5=Francaise 6=Deutsch 7=Polski 8=Cesky 9=Italiano 10=Espanol 11=Portugues 12=Русский 13=Eesti 14=Latviesu 15=Lietiviu 16=Nederlands 17=Hungarian 18=Turkce		
<b>4x0112</b>	<b>Summer night cool start, hour</b>	0-23	
	Setting for start time of summer night cooling function.		
<b>4x0113</b>	<b>Summer night cool start, minute</b>	0-59	
	Setting for start time of summer night cooling function.		
<b>4x0114</b>	<b>Summer night cool stop, hour</b>	0-23	
	Setting for stop time of summer night cooling function.		
<b>4x0115</b>	<b>Summer night cool stop, minute</b>	0-59	
	Setting for stop time of summer night cooling function.		
<b>4x0116</b>	<b>Reserve</b>		
<b>4x0117</b>	<b>Reserve</b>		
<b>4x0118</b>	<b>Morning boost time, hours</b>	0-23	
	Setting of morning boost time before normal operation.		
<b>4x0119</b>	<b>Morning boost time, minutes</b>	0-59	
	Setting of morning boost time before normal operation.		
<b>4x0120</b>	<b>Startup time</b>	0 - 600s	
	Setting of time for startup when the unit regulator is running with fixed signals.		
<b>4x0121</b>	<b>Start delay SA fan.</b>	0 - 600s	
	Setting of start delay time for the supply air fan.		
<b>4x0122</b>	<b>Start delay EA fan.</b>	0 - 600s	

	Setting of start delay time for the extract air fan after supply air fan has started.																										
4x0123	<b>Air flow unit</b>	0 -2																									
	Setting of air flow unit presented in the unit's handterminal and WEB. 0=l/s. 1=m3/s. 2=m3/h.																										
4x0124	<b>Reserve</b>																										
4x0125	<b>Year</b>	2000-2100																									
	Setting for the unit's internal clock.																										
4x0126	<b>Month</b>	1-12																									
	Setting for the unit's internal clock.																										
4x0127	<b>Date</b>	0-31																									
	Setting for the unit's internal clock.																										
4x0128	<b>Hour</b>	0-23																									
	Setting for the unit's internal clock.																										
4x0129	<b>Minute</b>	0-59																									
	Setting for the unit's internal clock.																										
4x0130	<b>Second</b>	0-59																									
	Setting for the unit's internal clock.																										
4x0131	<b>Time channel 1 status</b>	0-10,16-26																									
	<table border="0"> <tr> <td><b>Low speed</b></td> <td><b>Högfart</b></td> </tr> <tr> <td>0=Deactive</td> <td>16=Deactive</td> </tr> <tr> <td>1=Monday</td> <td>17=Monday</td> </tr> <tr> <td>2=Tuesday</td> <td>18=Tuesday</td> </tr> <tr> <td>3=Wednesday</td> <td>19=Wednesday</td> </tr> <tr> <td>4=Thursday.</td> <td>20=Thursday</td> </tr> <tr> <td>5=Friday</td> <td>21=Friday</td> </tr> <tr> <td>6=Saturday</td> <td>22=Saturday</td> </tr> <tr> <td>7=Sunday</td> <td>23=Sunday</td> </tr> <tr> <td>8=Monday..Friday</td> <td>24=Monday..Friday</td> </tr> <tr> <td>9=Monday..Sunday</td> <td>25=Monday..Sunday</td> </tr> <tr> <td>10=Saturday..Sunday</td> <td>26=Saturday..Sunday</td> </tr> </table>	<b>Low speed</b>	<b>Högfart</b>	0=Deactive	16=Deactive	1=Monday	17=Monday	2=Tuesday	18=Tuesday	3=Wednesday	19=Wednesday	4=Thursday.	20=Thursday	5=Friday	21=Friday	6=Saturday	22=Saturday	7=Sunday	23=Sunday	8=Monday..Friday	24=Monday..Friday	9=Monday..Sunday	25=Monday..Sunday	10=Saturday..Sunday	26=Saturday..Sunday		
<b>Low speed</b>	<b>Högfart</b>																										
0=Deactive	16=Deactive																										
1=Monday	17=Monday																										
2=Tuesday	18=Tuesday																										
3=Wednesday	19=Wednesday																										
4=Thursday.	20=Thursday																										
5=Friday	21=Friday																										
6=Saturday	22=Saturday																										
7=Sunday	23=Sunday																										
8=Monday..Friday	24=Monday..Friday																										
9=Monday..Sunday	25=Monday..Sunday																										
10=Saturday..Sunday	26=Saturday..Sunday																										
4x0132	<b>Time channel 1 start hour</b>	0-23																									
4x0133	<b>Time channel 1 start minute</b>	0-59																									
4x0134	<b>Time channel 1 stop hour</b>	0-23																									
4x0135	<b>Time channel 1 stop minute</b>	0-59																									
4x0136	<b>Time channel 2 status</b>	0-10,16-26																									
4x0137	<b>Time channel 2 start hour</b>	0-23																									
4x0138	<b>Time channel 2 start minute</b>	0-59																									
4x0139	<b>Time channel 2 stop hour</b>	0-23																									
4x0140	<b>Time channel 2 stop minute</b>	0-59																									
4x0141	<b>Time channel 3 status</b>	0-10,16-26																									
4x0142	<b>Time channel 3 start hour</b>	0-23																									
4x0143	<b>Time channel 3 start minute</b>	0-59																									
4x0144	<b>Time channel 3 stop hour</b>	0-23																									
4x0145	<b>Time channel 3 stop minute</b>	0-59																									
4x0146	<b>Time channel 4 status</b>	0-10,16-26																									
4x0147	<b>Time channel 4 start hour</b>	0-23																									
4x0148	<b>Time channel 4 start minute</b>	0-59																									

4x0149	Time channel 4 stop hour	0-23	
4x0150	Time channel 4 stop minute	0-59	
4x0151	Time channel 5 status	0-10,16-26	
4x0152	Time channel 5 start hour	0-23	
4x0153	Time channel 5 start minute	0-59	
4x0154	Time channel 5 stop hour	0-23	
4x0155	Time channel 5 stop minute	0-59	
4x0156	Time channel 6 status	0-10,16-26	
4x0157	Time channel 6 start hour	0-23	
4x0158	Time channel 6 start minute	0-59	
4x0159	Time channel 6 stop hour	0-23	
4x0160	Time channel 6 stop minute	0-59	
4x0161	Time channel 7 status	0-10,16-26	
4x0162	Time channel 7 start hour	0-23	
4x0163	Time channel 7 start minute	0-59	
4x0164	Time channel 7 stop hour	0-23	
4x0165	Time channel 7 stop minute	0-59	
4x0166	Time channel 8 status	0-10,16-26	
4x0167	Time channel 8 start hour	0-23	
4x0168	Time channel 8 start minute	0-59	
4x0169	Time channel 8 stop hour	0-23	
4x0170	Time channel 8 stop minute	0-59	
4x0171	Extended low speed op. Hours	0-23	
	Setting for extended low speed operation.		
4x0172	Extended low speed op. Minutes	0-59	
	Setting for extended low speed operation.		
4x0173	Extended high speed op. Hours	0-23	
	Setting for extended low speed operation.		
4x0174	Extended high speed op. Minutes	0-59	
	Setting for extended low speed operation.		
4x0175	Communication operation mode	0 - 4	
	Setting of unit operation mode from communication. 0=Auto operation. 1=Communication stop 1. 2=Communication low speed. 3=Communication high speed. 4=Communication stop 2 Summer night cool, intermittent night heat and morning boost functions works at stop 2.		
4x0176	Service periode alarm.	0-99	
	Setting for delay time in months before service alarm.		
4x0177	External alarm 1 delay	1 - 600s	
	Setting of delay time for external alarm no 1		
4x0178	External alarm 2 delay	1 - 600s	
	Setting of delay time for external alarm no 2		
4x0179	Int. Night heat SA pressure setpoint	20-750Pa	
	Intermittent night heat function, supply pressure setpoint during night heat.		

4x0180	<b>Int. Night heat EA pressure setpoint</b>	20-750Pa	
	Intermittent night heat function, extract pressure setpoint during night heat.		
4x0181	<b>Copy of Coil Status 1-16</b>	0-65535	
	Bit 0=1x0001 Bit 1=1x0002 Bit 15=1x0016		
4x0182	<b>Copy of Coil Statust 17-32</b>	0-65535	
	Bit 0=1x00017 Bit 1=1x00018 Bit 15=1x0032		
4x0183	<b>Copy of Coil Status 33-48</b>	0-65535	
	Bit 0=1x00033 Bit 1=1x00034 Bit 15=1x0048		
4x0184	<b>Heat relay periodic func.</b>	0-3	
	Setting of periodic operation. 0=Inactive 1=Pump 2=Pump+valve 3=Valve		
4x0185	<b>Cool relay 1 periodic func.</b>	0-3	
	Setting of periodic operation. 0=Inactive 1=Pump 2=Pump+valve 3=Valve		
4x0186	<b>Cool relay 2 periodic func.</b>	0-3	
	Setting of periodic operation. 0=Inactive 1=Pump 2=Pump+valve 3=Valve		
4x0187	<b>Slave control C-factor</b>	0.500 - 1.500	
	Slave regulator affection setting.		
4x0188	<b>Reserve</b>		
4x0189	<b>Reserve</b>		
4x0190	<b>Reserve</b>		
4x0191	<b>Reserve</b>		
4x0192	<b>Reserve</b>		
4x0193	<b>Reserve</b>		
4x0194	<b>Reserve</b>		
4x0195	<b>Reserve</b>		
4x0196	<b>Water heating periodic op. time</b>	0-60min	



	Setting of periodic op. time (minute).		
<b>4x0197</b>	<b>Water heating interval</b>	0-168h	
	Setting of water heating interval time (hour).		
<b>4x0198</b>	<b>Cool periodic op. time</b>	0-60min	
	Setting of periodic op. time (minute).		
<b>4x0199</b>	<b>Cool interval</b>	0-168h	
	Setting of cool interval time (hour).		
<b>4x0200</b>	<b>Reserve</b>		
<b>4x0201</b>	<b>EA/Room temperature (external) func.</b>	0-2	
	Setting of EA/Room temperature (external) function. 0= Inactive. 1= IQnomic. 2= Communication (4x0202).		
<b>4x0202</b>	<b>EA/Room temperature com.</b>	-55.00-125.00°C	
	Setting of EA/Room temperature via communication.		
<b>4x0203</b>	<b>Outdoor temperature (external) func.</b>	0-2	
	Setting of outdoor temperature (external) function. 0= Inactive. 1= IQnomic. 2= Communication (4x0204).		
<b>4x0204</b>	<b>Outdoor temperature com.</b>	-55.00-125.00°C	
	Setting of outdoor temperature via communication.		
<b>4x0205</b>	<b>Timeout temperature com.</b>	0-9999min	
	Setting of timeout for temperature via communication (4x0202, 4x0204).		
<b>4x0206</b>	<b>Flow at fire function.</b>	0-3	
	Setting for activating the air fan operation at fire function 0= Inactive. 1= SA. 2= EA. 3= SA+EA.		
<b>4x0207</b>	<b>Air fan down regulation func.</b>	0-2	
	Setting for activating the air fan down regulation function 0= Inactive. 1= SA. 2= SA+EA.		
<b>4x0208</b>	<b>SA speed at fire.</b>	10.00-100.00%	
	Setting of supply air speed at fire.		
<b>4x0209</b>	<b>EA speed at fire.</b>	10.00-100.00%	
	Setting of extract air speed at fire.		
<b>4x0210</b>	<b>Reserve</b>		
<b>4x0211</b>	<b>Reserve</b>		
<b>4x0212</b>	<b>Supply air min P-band.</b>	1.00 - 40.00	
	Supply air min regulator P-band setting.		
<b>4x0213</b>	<b>Supply air min C-factor.</b>	0.000 - 2.500	
	Supply air min regulator affection setting.		
<b>4x0214</b>	<b>Supply air max P-band.</b>	1.00 - 40.00	

	Supply air max regulator P-band setting.		
4x0215	Supply air max C-factor.	0.000 - 2.500	
	Supply air max regulator affection setting.		
4x0216	Year channel 1 function.	0 - 3	
	0 = Inactive. 1 = Stop. 2 = Low speed. 3 = High speed.		
4x0217	Year channel 1 start year.	2000 - 2099	
4x0218	Year channel 1 start month.	1 - 12	
4x0219	Year channel 1 start date.	1 - 31	
4x0220	Year channel 1 start hour.	0 - 23	
4x0221	Year channel 1 start minute.	0 - 59	
4x0222	Year channel 1 stop year.	2000 - 2099	
4x0223	Year channel 1 stop month.	1 - 12	
4x0224	Year channel 1 stop date.	1 - 31	
4x0225	Year channel 1 stop hour.	0 - 23	
4x0226	Year channel 1 stop minute.	0 - 59	
4x0227	Year channel 2 function.	0 - 3	
4x0228	Year channel 2 start year.	2000 - 2099	
4x0229	Year channel 2 start month.	1 - 12	
4x0230	Year channel 2 start date.	1 - 31	
4x0231	Year channel 2 start hour.	0 - 23	
4x0232	Year channel 2 start minute.	0 - 59	
4x0233	Year channel 2 stop year.	2000 - 2099	
4x0234	Year channel 2 stop month.	1 - 12	
4x0235	Year channel 2 stop date.	1 - 31	
4x0236	Year channel 2 stop hour.	0 - 23	
4x0237	Year channel 2 stop minute.	0 - 59	
4x0238	Year channel 3 function.	0 - 3	
4x0239	Year channel 3 start year.	2000 - 2099	
4x0240	Year channel 3 start month.	1 - 12	
4x0241	Year channel 3 start date.	1 - 31	
4x0242	Year channel 3 start hour.	0 - 23	
4x0243	Year channel 3 start minute.	0 - 59	
4x0244	Year channel 3 stop year.	2000 - 2099	
4x0245	Year channel 3 stop month.	1 - 12	
4x0246	Year channel 3 stop date.	1 - 31	
4x0247	Year channel 3 stop hour.	0 - 23	
4x0248	Year channel 3 stop minute.	0 - 59	
4x0249	Year channel 4 function.	0 - 3	
4x0250	Year channel 4 start year.	2000 - 2099	
4x0251	Year channel 4 start month.	1 - 12	
4x0252	Year channel 4 start date.	1 - 31	
4x0253	Year channel 4 start hour.	0 - 23	
4x0254	Year channel 4 start minute.	0 - 59	
4x0255	Year channel 4 stop year.	2000 - 2099	
4x0256	Year channel 4 stop month.	1 - 12	
4x0257	Year channel 4 stop date.	1 - 31	

4x0258	Year channel 4 stop hour.	0 - 23	
4x0259	Year channel 4 stop minute.	0 - 59	
4x0260	Year channel 5 function.	0 - 3	
4x0261	Year channel 5 start year.	2000 - 2099	
4x0262	Year channel 5 start month.	1 - 12	
4x0263	Year channel 5 start date.	1 - 31	
4x0264	Year channel 5 start hour.	0 - 23	
4x0265	Year channel 5 start minute.	0 - 59	
4x0266	Year channel 5 stop year.	2000 - 2099	
4x0267	Year channel 5 stop month.	1 - 12	
4x0268	Year channel 5 stop date.	1 - 31	
4x0269	Year channel 5 stop hour.	0 - 23	
4x0270	Year channel 5 stop minute.	0 - 59	
4x0271	Year channel 6 function.	0 - 3	
4x0272	Year channel 6 start year.	2000 - 2099	
4x0273	Year channel 6 start month.	1 - 12	
4x0274	Year channel 6 start date.	1 - 31	
4x0275	Year channel 6 start hour.	0 - 23	
4x0276	Year channel 6 start minute.	0 - 59	
4x0277	Year channel 6 stop year.	2000 - 2099	
4x0278	Year channel 6 stop month.	1 - 12	
4x0279	Year channel 6 stop date.	1 - 31	
4x0280	Year channel 6 stop hour.	0 - 23	
4x0281	Year channel 6 stop minute.	0 - 59	
4x0282	Year channel 7 function.	0 - 3	
4x0283	Year channel 7 start year.	2000 - 2099	
4x0284	Year channel 7 start month.	1 - 12	
4x0285	Year channel 7 start date.	1 - 31	
4x0286	Year channel 7 start hour.	0 - 23	
4x0287	Year channel 7 start minute.	0 - 59	
4x0288	Year channel 7 stop year.	2000 - 2099	
4x0289	Year channel 7 stop month.	1 - 12	
4x0290	Year channel 7 stop date.	1 - 31	
4x0291	Year channel 7 stop hour.	0 - 23	
4x0292	Year channel 7 stop minute.	0 - 59	
4x0293	Year channel 8 function.	0 - 3	
4x0294	Year channel 8 start year.	2000 - 2099	
4x0295	Year channel 8 start month.	1 - 12	
4x0296	Year channel 8 start date.	1 - 31	
4x0297	Year channel 8 start hour.	0 - 23	
4x0298	Year channel 8 start minute.	0 - 59	
4x0299	Year channel 8 stop year.	2000 - 2099	
4x0300	Year channel 8 stop month.	1 - 12	
4x0301	Year channel 8 stop date.	1 - 31	
4x0302	Year channel 8 stop hour.	0 - 23	
4x0303	Year channel 8 stop minute.	0 - 59	
4x0304	Filter select.	0 - 3	

	Setting for filter select function. 0=Inactive. 1=Supply air. 2=Extract air. 3=SA+EA.		
<b>4x0305</b>	<b>Prefilter select.</b>	0 - 3	
	Setting for prefilter select function. 0=Inactive. 1=Supply air. 2=Extract air. 3=SA+EA.		
<b>4x0306</b>	<b>SA prefilter alarm limit.</b>	10-1000Pa	
	Supply air prefilter pressure alarm limit setting.		
<b>4x0307</b>	<b>EA prefilter alarm limit.</b>	10-1000Pa	
	Extract air prefilter pressure alarm limit setting.		
<b>4x0308</b>	<b>Prefilter calibration mode.</b>	0 - 3	
	Setting for requiered filtercalibration. 0=Inactive. 1=SA+EA-Filter. 2=SA-Filter. 3=EA-Filter.		
<b>4x0309</b>	<b>Reserve</b>		
<b>4x0310</b>	<b>Reserve</b>		
<b>4x0311</b>	<b>Reserve</b>		
<b>4x0312</b>	<b>Reserve</b>		
<b>4x0313</b>	<b>Reserve</b>		
<b>4x0314</b>	<b>Reserve</b>		
<b>4x0315</b>	<b>Reserve</b>		
<b>4x0316</b>	<b>Reserve</b>		
<b>4x0317</b>	<b>Reserve</b>		
<b>4x0318</b>	<b>Reserve</b>		
<b>4x0319</b>	<b>Reserve</b>		
<b>4x0320</b>	<b>Reserve</b>		
<b>4x0321</b>	<b>Reserve</b>		
<b>4x0322</b>	<b>Reserve</b>		
<b>4x0323</b>	<b>Reserve</b>		

4x0324	Reserve		
4x0325	Reserve		
4x0326	<b>Preheating function.</b>	0 - 4	
	Setting of preheating function. 0=Inactive. 1=El. coil P/P. 2=El. coil 0-10V. 3=Water coil with FP. 4=Water coil without FP.		
4x0327	<b>Preheating setpoint.</b>	-30.00-30.00°C	
	Setting of preheating temperature setpoint.		
4x0328	Reserve		
4x0329	Reserve		
4x0330	Reserve		
4x0331	Reserve		
4x0332	Reserve		
4x0333	Reserve		
4x0334	Reserve		
4x0335	Reserve		
4x0336	Reserve		
4x0337	<b>Preheat P-band.</b>	1.00 - 40.00	
	Preheat regulator P-band setting.		
4x0338	<b>Preheat C-factor.</b>	0.000 - 2.500	
	Preheat regulator affection setting.		
4x0339	Reserve		
4x0340	Reserve		
4x0341	Reserve		
4x0342	Reserve		
4x0343	Reserve		
4x0344	Reserve		
4x0345	Reserve		
4x0346	Reserve		

<b>4x0347</b>	<b>Reserve</b>		
<b>4x0348</b>	<b>Reserve</b>		
<b>4x0349</b>	<b>Reserve</b>		
<b>4x0350</b>	<b>SA Filter calculated alarm level</b>	5.00-20.00%	
	Supply air filter calculated alarm limit setting.		
<b>4x0351</b>	<b>EA Filter calculated alarm level</b>	5.00-20.00%	
	Extract air filter calculated alarm limit setting.		
<b>4x0352</b>	<b>Mode digital output relay 1</b>	0-8	
	Setting of mode output relay 1 function. 0=Damper. 1=Operation. 2=Low speed. 3=High speed. 4=Alarm A. 5=Alarm B. 6=Heating. 7=Cooling 1. 8=Cooling 2.		
<b>4x0353</b>	<b>Mode digital output relay 2</b>	0-8	
	Setting of mode output relay 2 function. 0=Damper. 1=Operation. 2=Low speed. 3=High speed. 4=Alarm A. 5=Alarm B. 6=Heating. 7=Cooling 1. 8=Cooling 2.		
<b>4x0354</b>	<b>Mode digital input 1</b>	0-6	
	Setting of mode input 1 function. 0=Stop. 1=Low speed. 2=High speed. 3=Alarm 1. 4=Alarm 2. 5=Reset. 6=Fire.		
<b>4x0355</b>	<b>Mode digital input 2</b>	0-6	

	Setting of mode input 2 function. 0=Stop. 1=Low speed. 2=High speed. 3=Alarm 1. 4=Alarm 2. 5=Reset. 6=Fire.		
<b>4x0356</b>	<b>Manual morning boost time hour</b>	0-23	
	Setting of manual morning boost time before normal operation.		
<b>4x0357</b>	<b>Manual morning boost time minutes</b>	0-59	
	Setting of manual morning boost time before normal operation.		
<b>4x0358</b>	<b>Airing temp set</b>	10.00-20.00	
	Setting of airing temperature setpoint.		
<b>4x0359</b>	<b>Airing time set</b>	10-60	
	Setting of airing time in minutes.		
<b>4x0360</b>	<b>Manual operation drift mode</b>	0-4	
	Setting of manual operation drift mode. 0=Normal operation. 1=Extended operation. 2=Airing. 3=Heating. 4=Heating+Recirc.		

