



by Swegon

© Swegon Air Management Limited South Street, Whitstable, Kent CT5 3DU Tel: +44 (0)1227 276100 Email: actionair@swegon.com www.swegon.com/uk

Installation Detail

If your proposed installation details differ from that shown here, please discuss this with the authority having jurisdiction, referencing this documentation.

Deviation from this drawing requires approval of the relevant authority.

Connecting ductwork omitted for clarity.

Ductwork must be independently supported.

There must be an appropriate break-away joint between the damper and the connecting ductwork on both sides of the installation.

A minimum of 200mm between fire dampers installed in separate ducts and 75mm between fire damper and construction elements/edges needs to be observed unless otherwise specified in the drawing.



SCAN ME

Please refer to the DoP for latest classifications for CE/UKCA compliance and the Installation, Operation and Maintenance Guide

A Initial Issue		JPM	12/07/22	
Rev:	Rev: Comments:		Ву:	Date:
Drawn By: J. Mount		Date: 16/06/2022		
Checked By: M.Kimberley		Date: 12/07/2022		
Approved By: S.Gore		Date	: 12/0	7/2022

Description:

VERTICAL APPLICATION

CSS - IN PLASTERBOARD WALL

Damper Size Range (mm) Ø100mm. - Ø355mm.

 Reference No:
 Sheet
 Rev

 AAF13413
 1 of 1
 A