# CASA R7-H Genius

Technical catalogue



#### **QUICK FACTS**

- CASA Genius control system
- Automatic rotor speed control for demand controlled humidity function as standard
- Automatic summer function and passive cooling
- Anti-frost protection ensures continuous ventilation
- External coils for heating and cooling as an option
- Can be connected to the automated building management system (I/O/Modbus)
- Mounted on a firm foundation

Air flow range	60-208 l/s   216-749 m³/h
Dimensions, w x l x h	930 x 571 x 712 mm
Duct outlets	4 x Ø 200 mm
Energy calculations and acoustic data	procasa.swegon.com
Connection power	360 W   1760 W
Power connection	230 V, 50 Hz, 10 A
Fans	340 W, EC
Filters	ISO ePM1 50% (F7) filters for supply air and extract air
Colour	Exterior White, RAL 9016 (corresponds to NCS S0502-G50Y)

UNIT TECHNICAL CONTENT



## Content

Technical description	3
CASA Genius control	
Design data	ε
Air flows	
Acoustic data	10
Dimensions and weight	11
Functional diagram	12
External connections	
Internal connections	15
Installation options	16
Product codes	18





## **Technical description**

### Swegon CASA R7-H Genius

Air handling unit with rotary heat exchanger (930 x 571 x 712 mm,  $\emptyset$  200 mm), suitable for large houses (208 l/s, 450 m²), office or conference rooms. The intelligent demand-controlled humidity function is standard.

### Indoor environmental quality

#### **Ventilation control**

The unit is controlled steplessly with automation functions to quarantee the best indoor environmental quality. The user can select five operating modes home, away, boost, travelling and home+ by using control panel, cooker hood or Swegon CASA app. Operation modes can be automated with unit's weekly programs.

#### Temperature control


The supply air temperature is controlled with heat exchanger and if needed with optional heating or cooling element.

The unit has automatic summer time detection. The function sets lower supply air temperature setpoint and boost ventilation in order to bring more fresh outdoor air to the apartment during summer nights.

#### **Available variants**

Standard units are available in following variants:

- Unit with out postheater
- Unit with 1400 W postheater





### Components

#### Fans

CASA R7-H is equipped with energy efficient EC fans.

#### **Filter**

The ventilation unit is equipped with ISO ePM1 50% (F7) filters for supply air and extract air. The need of filter replacement is indicated on the control panel and on the CASA cooker hood.

#### Heat exchanger

The ventilation unit is equipped with a **speed controlled rotary heat exchanger**. Heath exchanger is controlled either to maintain constant supply air temperature or to achieve maximum energy efficiency (winter mode).

#### **External connections**

All connections can be made without opening the electrical box. Plug-in modules are available for external connections. Wide variety of IO functions are available.

The ventilation unit is equipped with In-build Modbus. Modbus cabling can be made easily with external cable (SEC) or module (SEM). Unit can be fully controlled with Modbus and all external IO's can be configured to Modbus usage.

### **Protective functions**

#### The heat exchanger freeze protection

The defrosting function guarantees continuous ventilation and maintains units performance even during extreme conditions. If reheat can't maintain sufficient supply air temperature, the air flows are reduced.

#### The fan overheating protection

The fan overheat protection stops the fan if the temperature rises too high and is reseted automatically. If protection stops the fans an alarm is generated.

#### Rotor guard

Rotor guard detects that the rotor is working. Malfunction generates an alarm.

#### Cold supply air

The ventilation unit has built-in condensation protection. If the supply air is too cold, the ventilation unit stops and an alarm is generated

#### High temperature

If supply air or units internal temperature is detected dangerously high the unit is stopped and an alarm is generated.

#### Temperature sensors

If a sensor fault is detected, an alarm is generated. If the faulted sensor is critical the ventilation unit is stopped. The ventilation unit returns to normal mode once the fault has been corrected.






### The delivery includes

- Ventilation unit
- Quick Guide
- Installation and commissioning instruction
- Product fiche

#### Standard connections

- Power cord with earthed plug (2 m)
- Modular cable with RJ9 connector (1.5 m)
- Freely configurable I/O contacts for connection of accessories (2 pcs.)



- 1. Temperature sensor
- Fan
- 3. Operating switch
- 4. Reheating module 1400 W (optional)
- 5. Genius control board
- 6. ISO ePM1 50% (F7) filters
- 7. Rotor
- 8. Rotor motor
- 9. Door
- 10. Sensor package, RH



## **Swegon CASA Genius**

## Intelligent control of the ventilation

With Swegon CASA Genius residents can monitor the indoor air quality (RH, CO2, VOC, °C), adjust ventilation to their wishes or let the intelligent control to adjust ventilation automatically while saving energy and providing fresh and healthy indoor air.



#### The Swegon CASA control panel (GC10)

Wall-mounted touch screen for external or flush mounting. From the touch screen user can monitor ventilation, change ventilation mode, change the settings and commission the ventilation unit. The screen can be connected to the home WLAN, enabling the ventilation to be controlled remotely from a Swegon CASA mobile app



#### The Swegon CASA app

With Swegon CASA app residents can use all the control functions remotely from their own smartphone. Users get more information about their home's air quality as well as valuable instructions and advice about the ventilation (requires Swegon Genius control panel).



#### The CASA Service app

for quick and easy commissioning. The app works locally together with the ventilation unit and doesn't require connection to network. The app defines the I/O connections, presets the fan speeds that correspond to specified air volumes, as well as automatically sets air volumes for home and boost mode. Finished settings can be saved in the app and copied to the next apartment (requires Swegon Genius control panel).



#### Swegon CASA cooker hood

With cooker hoods, it is possible to control the ventilation unit's operating mode (home, away, boost), the cooker hood's shut-off damper and the lighting in the hood. The system balances the ventilation automatically when using the cooker hood.




#### The Swegon CASA HOME/AWAY/BOOST control switch (GC04)

Wall-mounted control switch for selecting boost, home and away modes.



#### Home automation

Can be connected to the home automation for centralised monitoring and control, either directly via configurable I/O or with the aid of a separate Modbus connection module (SEM).





#### **Basic** modes

You can switch as required to an appropriate operating mode or let the pre-programmed weekly clock switch operating mode according to the diurnal rhythm you want.



#### Home

Normal air flow. Sufficient amount of fresh indoor air to ensure the wellbeing of the residents and the structural building elements when there are people in the home.



#### Home+

Higher air flow. Can be used when more ventilation is required. The home owner can change the efficiency of the operating mode from the settings.



#### **Boost**

High air flow. Used if the ventilation requirement increases, for example, when cooking, taking a bath or drying laundry, or when an unusually large number of people are in the home.



#### Away

Low air flow. Reduces the energy consumption when nobody is present in the home.



#### **Travelling**

Very low air flow and lower supply air temperature. Used when nobody is present in the home.

#### **Automatic functions**

The intelligent ventilation monitors the quality of the indoor air and adjusts the ventilation automatically.



RH Humidity 35%

#### Automatic RH system included as standard

Humidity automation removes damaging moisture. The intelligent control analyses the indoor air continuously and regulates the ventilation steplessly so that excess moisture is removed, for example when you are washing.




CO<sub>2</sub> Carbon dioxide 520 PPM

#### Automatic CO2 system as optional equipment

Automatically lowers the ventilation and saves energy when nobody is in the home. When the residents are at home, the ventilation is automatically boosted to bring exactly the right amount of fresh air into the home.






#### Automatic VOC system as optional equipment

The automatic air quality system boosts the ventilation if pollution, odours or vapours (evaporating organic compounds) are detected in the indoor air.





## Design data



The ventilation unit has been supplied in the left-hand version (L) and it can be changed to right-hand version (R) on site. Note! Always check the correct duct sequence in the installation instructions.







Energy calculation, functional diagram and acoustic data on ProCASA.

procasa.swegon.com










3D models and CAD dimension sketches for all Swegon CASA products are available from MagiCloud. You can download DXF files directly from MagiCloud or use a MagiCAD plugin to transfer dimension sketches to the Revit and AutoCAD software packages.


www.magicloud.com





## Air flows





## Acoustic data

See acoustic data on ProCASA. procasa.swegon.com









## Dimensions and weight

#### **Dimensions**

Weight of the unit: 82 kg








## Functional diagram

### Functional diagram



Device	Description	Modbus register
T1	L: Temperature sensor, outdoor air R: Temperature sensor, extract air	3x6201 (0,1°C)
T3 TSP	L: Temperature sensor, extract air R: Temperature sensor, outdoor air	3x6204 (0,1°C)
T4	L: Temperature sensor, supply air R: Temperature sensor, exhaust air	3x6203 (0,1°C)
T5	L: Temperature sensor, exhaust air R: Temperature sensor, supply air	3x6205 (0,1°C)
TZ01	Manual overheat protection 60°C post heater	Alarm 3x6117
TZA1	Automatic overheat protection 50°C post heater	Alarm 3x6117
Filter 1	Air filter ISO ePM1 50% (F7)	Service reminder info 3x6129
Filter 2	Air filter ISO ePM1 50% (F7)	Service reminder info 3x6129
F1	L: Extract fan R: Supply fan	Control 3x6304(%), RPM 3x6306
F2	L: Supply fan R: Extract fan	Control 3x6303(%), RPM 3x6305
PH	Post heater (1400W), controlled steplessly according to demand (optional)	Control 3x6317 (%)
HE	Rotating heat exchanger (Rotor)	
НЕ М	A heat exchanger motor which speed is steplessly controlled based on the temperature and humidity of the supply air	Control 3x6332 (0.1xRPM)
S1	Use Switch. Note! power off the unit by removing the socket from the Mains when Service	
RH	Humidity sensor for RH automation	RH 3x6214






#### Functional diagram

### **Duct actuators**

- FIELD CONFIGURATION AU
- FIELD CONNECTION SU
- ◆ FYSICAL CONNECTION
- ALTERNATIVE CONNECTION (Note: an additional relay is required for DO outputs)



Device	Description
T6-T9	Temperature sensor. Connection to the SET module. The sensor must be defined on the control panel.
SD1, SD2	Duct Plate for Outdoor/Exhaust duct.
FLK	Duct filter in combination with an electric pre heater (SDHE)
SDHWM	Ground Liquid preheating/cooling coil for outdoor air duct. (Inc SET, heating/cooling coil, sensor)
SDHE	Electrical duct heater for Supply/Outdoor air duct (Inc. SET, duct heater and sensors) Note! A duct filter (FLK) is required for the preheater.
SDHW	Heating coil for supply air duct (Inc. SET, three-way valve + actuator, heating coil, sensors).
SDCW	Cooling coil for supply air duct (Inc. SET, three-way valve + actuator, cooling coil, sensors).
CO2	CO2 sensor for CO2 automation
VOC	VOC sensor for VOC automation
SEM	Modbus module (Inc. 2m RJ-45 cable)
SEC	IO extension module (Inc. 2m RJ-45 cable)
SET	Connection module for duct batteries and temperature sensors. (Inc. 2 x 3m RJ-45 cable)
APP	Swegon CASA mobile application for ventilation control and monitoring. Requires a Genius control panel (GC10) to operate.
UP GC10	Genius control panel that can be connected to Swegon CASA application via WiFi.
GC04	Control switch to select boost, home and away mode.
GC03	Control switch to select boost mode.
СН	Cooker hood. The CASA hood is connected to the ventilation unit with a modular cable. With other hoods, you can control the cooking function with a switch input that is determined for the function.






## **External connections**

#### **External connections**

### **CASA Genius**



**SEC** IO extension cable with Modbus RTU


**SEM** IO extension module with relay and Modbus RTU (input and output connections)

**SET** IO extension module for control of external accessories





#### Internal connections



Device	Description
T1	L: Temperature sensor, outdoor air R: Temperature sensor, extract air
T3 TSP	L: Temperature sensor, extract air R: Temperature sensor, outdoor air
T4	L: Temperature sensor, supply air R: Temperature sensor, exhaust air
T5	L: Temperature sensor, exhaust air R: Temperature sensor, supply air
PH	Air heater, post heating
TZ01	Manual overheat protection
TZA1	Automatic overheat protection
F1	L: Extract fan R: Supply fan
F2	L: Supply fan R: Extract fan
М	Rotor's motor
S1	Use Switch
RH	Humidity sensor
UI	Connectors for control panel/cooker hood
SEC/SEM	Connector for connecting the SEC or SEM module
SET 1&2	Connectors for connecting the SET module
5V/24V	24V voltage output (IO max 125 mA/3W)
IO 1&2	Two general-purpose IO connectors





## Installation options

#### Ventilation unit installation site

The ambient temperature where the ventilation unit will be installed must be between +10 - (+50) °C.

**Note!** Unit has no condesation drain. Therefore it's not suitable in houses where unit's extract air humidity may be high. (i.e. sauna, spa, etc.)

#### Mounting on the floor


The unit should be installed on the floor. The device is heavy. Make sure that the mounting base will withstand its weight.

The rear edge of the unit must be at least 50 mm off the wall.

Free space in front of the maintenance door of the unit must be at least 1200 mm and above the electrical box at least 250 mm.

#### Changing flow direction

The ventilation unit has been supplied in the left-hand version (L) and it can be changed to right-hand version (R) on site.











## **Product codes**

Product	Product code	GTIN
CASA R7-H Genius L/R RH	R07HL00G00H	6430080090266
CASA R7-H Genius L/R 1400W RH	R07HL14G00H	6430080090273





## **CASA - Accessories**

Control accessories	Part no.	GTIN
GC10 CASA Genius control panel and WiFi	GC10	643008009084
GC10 control panel + 10 m long cable	GC14	6430080090853
GC10 control panel + 10 m long cable + frame	GC15	643008009086
GC10 control panel + frame	GC16	643008009087
Frame for control panel GC10	102SAK	6415879066752
CASA Genius boost/home/away control button	GC04	6430080090013
Building automation	Part no.	GTIN
Modbus connection module	SEM	6415879067346
Connection cable (configurable I/O) for Genius ventilation units	SEC	6415879067353
Room temperature sensor, total package with connection unit for ventilation units. The sensor is installed on the wall or in a recessed junction box (60 mm between holes).	WSTC	6415879069395
Automatic functions	Part no.	GTIN
RH + CO2 automation	GRHCO2	6430080091454
RH + CO2 + VOC automation	GRHCV	6430080091461
	Part no.	<b>GTIN</b> 6415879068060
Cooling coil package Ø 200	SDCW200	6415879068060
Cooling coil package Ø 200	1	1
Waterborne air coolers Cooling coil package Ø 200  Waterborne air heaters Heating coil package Ø 200	SDCW200	6415879068060
Cooling coil package Ø 200  Waterborne air heaters  Heating coil package Ø 200	Part no. SDHW200	6415879068060 <b>GTIN</b> 6415879068930
Cooling coil package Ø 200  Waterborne air heaters  Heating coil package Ø 200	Part no. SDHW200  Part no.	6415879068060 <b>GTIN</b>
Cooling coil package Ø 200  Waterborne air heaters  Heating coil package Ø 200  Brine air heater/cooler for ground source heat pump	Part no. SDHW200	6415879068060 <b>GTIN</b> 6415879068930
Waterborne air heaters Heating coil package Ø 200  Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4	Part no. SDHW200  Part no. SDHW250F	GTIN  6415879068930  GTIN  6415879068930  GTIN  6415879068084
Waterborne air heaters  Heating coil package Ø 200  Brine air heater/cooler for ground source heat pump  Heating/cooling coil Ø250, G4  Electric air heater	Part no. SDHW250F  Part no.	GTIN  6415879068060  GTIN  6415879068930  GTIN  6415879068084
Waterborne air heaters Heating coil package Ø 200  Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4  Electric air heater Electric heater Ø 200	Part no. SDHW200  Part no. SDHW250F  Part no. SDHE200-1T	GTIN 6415879068060 GTIN 6415879068930 GTIN 6415879068084 GTIN 6415879067254
Cooling coil package Ø 200  Waterborne air heaters	Part no. SDHW250F  Part no.	GTIN  6415879068060  GTIN  6415879068930  GTIN  6415879068084
Waterborne air heaters  Heating coil package Ø 200  Brine air heater/cooler for ground source heat pump  Heating/cooling coil Ø250, G4  Electric air heater  Electric heater Ø 200  Prefilter box Ø 200 mm, G4	Part no. SDHW200  Part no. SDHW250F  Part no. SDHE200-1T FLK20	GTIN  6415879068060  GTIN  6415879068930  GTIN  6415879068084  GTIN  6415879067254  6415879067490
Waterborne air heaters Heating coil package Ø 200  Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4  Electric air heater Electric heater Ø 200 Prefilter box Ø 200 mm, G4	Part no. SDHW200  Part no. SDHW250F  Part no. SDHE200-1T FLK20  Part no.	GTIN  6415879068060  GTIN  6415879068930  GTIN  6415879068084  GTIN  6415879067254  6415879067490  GTIN
Waterborne air heaters Heating coil package Ø 200  Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4  Electric air heater Electric heater Ø 200	Part no. SDHW200  Part no. SDHW250F  Part no. SDHE200-1T FLK20	GTIN  6415879068060  GTIN  6415879068930  GTIN  6415879068084  GTIN  6415879067254  6415879067490
Waterborne air heaters  Heating coil package Ø 200  Brine air heater/cooler for ground source heat pump  Heating/cooling coil Ø250, G4  Electric air heater  Electric heater Ø 200  Prefilter box Ø 200 mm, G4  Duct mounted shut-off dampers  Damper Ø 200 mm	Part no. SDHW250F  Part no. SDHW250F  Part no. SDHE200-1T FLK20  Part no. SDD200	GTIN  6415879068060  GTIN  6415879068930  GTIN  6415879068084  GTIN  6415879067254  6415879067490  GTIN  6415879070049
Waterborne air heaters Heating coil package Ø 200  Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4  Electric air heater Electric heater Ø 200 Prefilter box Ø 200 mm, G4  Duct mounted shut-off dampers Damper Ø 200 mm	Part no. SDHW200  Part no. SDHW250F  Part no. SDHE200-1T FLK20  Part no. SDD200	GTIN  6415879068060  GTIN  6415879068930  GTIN  6415879068084  GTIN  6415879067254  6415879067490  GTIN  6415879070049
Waterborne air heaters Heating coil package Ø 200  Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4  Electric air heater Electric heater Ø 200 Prefilter box Ø 200 mm, G4  Duct mounted shut-off dampers Damper Ø 200 mm  Other accessories  Connection module for control of the duct mounted air heater/cooler / control of shut-off dampers	Part no. SDHW250F  Part no. SDHW250F  Part no. SDHE200-1T FLK20  Part no. SDD200	GTIN  6415879068060  GTIN  6415879068930  GTIN  6415879068084  GTIN  6415879067254  6415879067490  GTIN  6415879070049
Waterborne air heaters Heating coil package Ø 200  Brine air heater/cooler for ground source heat pump Heating/cooling coil Ø250, G4  Electric air heater Electric heater Ø 200 Prefilter box Ø 200 mm, G4  Duct mounted shut-off dampers Damper Ø 200 mm	Part no. SDHW200  Part no. SDHW250F  Part no. SDHE200-1T FLK20  Part no. SDD200	GTIN  6415879068060  GTIN  6415879068930  GTIN  6415879068084  GTIN  6415879067254  6415879067490  GTIN  6415879070049



# Feel good **inside**



